

**RESERVDLSLISTA  
SPARE PARTS LIST  
ERSATZTEILLISTE  
LISTE DE PIÉCES DE RECHANGE**

**302 HD 602 H**

Ref. No	Benämning	Description	Bezeichnung	Description	Ant. Qty. Anz. Qte.	302 HD	602 H
						Det.nr Part. No. Teil.Nr. Piéce No	Det.nr Part. No. Teil.Nr. Piéce No
1	Toppklack	Saddle	Tragkopf	Tête de levée	1	13606	13606
2	Lock	Cover	Deckel	Couvercle	1	26524	26523
3	Toppklacksfäste	Saddle carrier	Tragkopfsbefestigung	Support de tête de levée	1	13067	23523
4	Axel	Axle	Achse	Axe	1	16431	16431
5	Huvudmutter	Head nut	Hauptmutter	Ecrou supérieur	1	13847	13847
6	Mantelrör	Tank tube	Mantelrohr	Réservoir	1	13211	13047
7	Lyftkolv, kpl	Lifting piston, cpl	Hebekolben, kpl	Piston élévateur, cpl	1	20187	13317
8	Cylinderrör	Cylinder tube	Zylinderrohr	Tube cylindrique	1	13990	13989
9	Avlastningsaxel	Release shaft	Entlastungswelle	Axe de descente	1	27639	27639
10	Pumpspak, kpl	Pump handle, cpl	Pumpenhebel, kpl	Levier, cpl	1	20223	20223
11	Pumparm	Pump arm	Pumpenarm	Bras de pompe	1	16340	16340
12	Pedal	Pedal	Hebel	Pédale	1	13059	13059
13	Pumpfjäder	Pump spring	Pumpenfeder	Ressort	1	13250	13250
14	Länk	Link	Gelenk	Chaînon	2	13193	13193
15	Länkaxel	Link Axle	Gelenkachse	Axe de chaînon	1	13223	13223
16	Pumpkolv, kpl	Pump piston, cpl	Pumpenkolben, kpl	Piston, cpl	1	16521	16521
17	Pumplopp, kpl	Pump cylinder, cpl	Pumpenzylinder, kpl	Cylindre, cpl	1	20189	20189
18	Pumphus	Pump housing	Pumpengehäuse	Corps de pompe	1	27694	27694
19	Tapphylsa	Pin housing	Stiftgehäuse	Joint	1	16498	16498
20	Axel	Axle	Achse	Axe	1	13306	13306
21	Hjul	Wheel	Rad	Roue	2	8968	8968
22	Länkhjul, kpl	Link wheel, cpl	Gelenkrad, kpl	Roue pivotant, cpl	2	13320	13320
23	Axel	Axle	Achse	Axe	1	20476	20476
24	Ram och lyftarm, kpl	Frame and lifting arm, cpl	Achse und Hebearm, kpl	Axe et bras de levage, cpl	1	27689	27688
25	Hjul	Wheel	Rad	Roue	2	16784	16784
26	Axel	Axle	Achse	Axe	1	13311	16429
27	Linjal	Ruler	Gelenk	Bras de support	2	13063	13070
28	Lyftarmsfjäder	Lift arm spring	Hebearmfeder	Ressort	1	27565	27513
29	Hydraulaggregat, kpl	Hydraulic unit, cpl	Hydraulikaggregat, kpl	Pompe hydraulique, cpl	1	20186	20537
30	Packningssats	Repair kit	Dichtungssatz	Pochette kit	1	17872	17872
31	Kompletteringsats	Replenishment kit	Ergänzungsatz	Kit complémentaire	1	29498	29498
32	Handtag	Handle	Handgriff	Poignée	2	15058	15058
	Olja	Oil	Öl	Huile	0,31	NIKE 500	NIKE 500

Jämförelsetabell olja/Comparison table oil/Vergleichstabelle Öl/Tableau de comparaison huile					
	OK	ESSO	MOBIL	SHELL	CASTROL
NIKE 500	Delta Oil 32	Nuto HP 32	DTE Oil 24	TELLUS Oil 32	Hyspin AWS 32
NIKE 400	Delta Oil 10	Nuto HP 15	DTE Oil 11	TELLUS Oil 10	Hyspin AWS 10

Vid reparationer: se reparationsanvisning nr 2 i verkstadshandboken.

At Repairs: please see repair instruction No 2 in the workshop manual.

Bei Reparaturen: Siehe Reparaturanweisung Nr. 2 in dem Werkstatt-Handbuch.

Lors de réparation: voir instruction no. 2 dans le manuel de réparation.

**ALWAYS USE NIKE ORIGINAL SPARE PARTS**

